

Ford Galaxy / S-max / Edge 2015-



Unteres Blech einhaken



Hook in lower metal plate



Konsole wie abgebildet positionieren
Beiliegende Schraube ins hintere Blech eindrehen



Position console as illustrated
Install enclosed screw into rear metal plate



Änderungen vorbehalten Subject to change

Ford Galaxy / S-max / Edge 2015-



Accrochez la tôle inférieure



Enganche la chapa inferior



Positionnez la console comme illustré
Vissez la vis jointe dans la tôle de derrière



Posicione la consola como mostrado
Instale el tornillo adjunto en la chapa trasera



Nous nous réservons la possibilité de modification Salvo posibles modificaciones

Ford Galaxy / S-max / Edge 2015-



Onderste metalen lip inhaken



Zaczepic dolna blaszke



Konsole zoals afgebeeld positioneren
Bijgevoegde schroef in de achterste plaat draaien



Uchwyt umiescic jak na przedstawionym zdjeciu.
Zalaczona srube w tylna blaszke wkręcic



Nous nous réservons la possibilité de modification Salvo posibles modificaciones